

Troubleshooting

■ no cooker



Use my pots only, these are designed for induction cooker plate.

Put cookware on a cooking zone before you start it. Use proper pot and pan size which is large enough to cover the surface unit element. If you cannot activate the appliance just touch for 5 seconds the lock symbol to activate or de-activate the appliance.

■ no Wi-Fi



In case of low signal or loss of Wi-Fi

In most cases a simple router restart should solve the problem. The router and the TV-box are in the service cupboard, which is located next to the entrance. Switch off both boxes (with the red button on the connector) for 5 minutes, then switch it back. They should restart and be operational in a few minutes. –pic 1

■ no electricity



In case of no electricity

First please check the surrounding area – stairway, street lights etc.- for electricity to make sure it is only affecting the flat. If it is only affecting the whole or parts of the apartment, please check the fuse box. The main and the rest fuse boxes are in the service cupboard. All fuses should be in the „up” position. If any are switched off (down) please turn them on (up). -pic 1

■ no heating or no hot water



In case of no heating

The heating and the hot water is provided by a gas furnace in the apartment. If there is a brief electricity or gas outage the furnace huts itself off due to safety reasons. If it does not restarts itself automatically after such an event, you can restart it manually by pushing the reset button. The furnace is in the back of the bigger bathroom in the cupboard. Please only use the reset button, do not push anything else as that could cause malfunction.–pic 2

